

INSTRUCTION MANUAL

K25SDL Heavy Duty Air Compressor (240V) 100 litres / 3hp 13.1 Displacement



C511



ACN 001 865 872 ABN 57 001 865 872

RELIABILITY IN AIR POWER

NSW:

115 Beaconsfield Street
Silverwater NSW 2128
PH : (02) 9648 3099
FAX :(02) 9648 3362

QLD:

Unit 11, 97 Jijaws St.,
Sumner Park QLD 4074
PH : (07) 3279 1213
FAX :(07) 3279 1762

VIC:

PH : 1300 667 579
FAX :(02) 9648 3362

SA: (Statewide Agencies P/L)

7/400 Grand Junction Rd
Mansfield Park SA 5012
PH : 1300 667 579
FAX: (08) 8347 4660

WA: (Air & Power P/L)

7-9 Fisher St
Belmont WA 6904
PH : (08) 9479 4220
FAX :(08) 9277 4040

INSTRUCTION AND PARTS LIST

MODEL: K25

MACHINERYHOUSE

PILOT AIR COMPRESSORS: THE FIVE "S" ADVANTAGE
SUPERIOR PRODUCT, SPECIALISTS, SERIES, SUPPORT, SERVICE

www.pilotair.com.au

USER GUIDE

Congratulations on the purchase of a PILOT air compressor. This unit has been designed to provide reliable and trouble free usage in servicing your compressed air requirements.

Please take a moment to familiarise yourself with the information contained in the following sections of this guide before attempting to operate this unit.

LOCATION OF UNIT:

For optimum efficiency locate unit in a clean, dry and cool environment with good ventilation. Avoid placing obstacles either on or around unit to facilitate maximum air flow and cooling.

OPERATION:

NOTE:

**CHECK OIL LEVEL BEFORE USE IN CASE OF LOSSES
INCURRED DURING SHIPPING**

A) ELECTRIC UNITS

Ensure ON/OFF switch is located on the pressure switch is in an ON/OFF position (down), before inserting power plug into appropriate receptacle and applying power.

Unit can then be switched on using the ON/OFF switch. The pressure switch will automatically start and stop the compressor when the air receiver drops below or reaches factory set cut-in and cut-out pressures respectively.

NOTE:

**ALWAYS SWITCH UNIT ON AND OFF VIA
PRESSURE SWITCH TO ENSURE THE UNIT
DOES NOT START AGAINST HIGH PRESSURE**

IMPORTANT:

**TO PREVENT DAMAGE TO UNIT OR PERSONS DO NOT
ATTEMPT TO MODIFY, BYPASS OR REMOVE PRESSURE
SWITCH OR SAFETY VALVE IN ANY WAY.
“TM” OR “K” SERIES ARE DESIGNED TO OPERATE TO
A MAXIMUM PRESSURE OF 10 BAR.**

The air receiver is equipped with a safety valve to release pressure in the event of a pressure switch cut-out failure. To prevent damage to the unit, do not attempt to modify, bypass or remove the pressure switch or safety valve in anyway.

The motor features a manual overload protection (where fitted). In poor power conditions or motor over temperature conditions, this overload protector will cut power to the motor. To reset, wait for the motor to cool then press reset button. If problems persist, check for power ratings, faulty power or poor connections.

B) PETROL/DIESEL DRIVEN

Please refer to OEM documentation in reference to care and operation of your petrol/diesel engine.

This unit has been designed to “idle down” to minimum operating speeds when factory set cut-out pressures are reached. This saves both fuel consumption and wear on moving parts. When pressure drops to set cut-in pressures the unit will automatically resume pumping at normal operating speeds.

To facilitate easy starting of the unit and to ensure no damage to the electric starter (where fitted) always open the “EASY START” valve until the unit is operating and then close for normal operation. This valve is located on the motor/pump platform (models K25P,K30P) or in the discharge pipe from the pump to the air receiver (other models).

SAFETY

- Pressure vessels (air receivers) are a type of plant, and as such, **MAY** be required to be registered with the relevant statutory authority in your state. Regulations regarding plant registration vary from state to state. Check with your relevant government authority about plant registration.
- Compressed air can be dangerous. Never point compressed air tools or equipment towards another person.
- After use, drain all residual air pressure or engage outlet tap to prevent accidental discharge by children.
- Keep clear of compressor pump during and after operation. Heat build up in the pump may cause burns to unwary.
- Never operate the unit without factory fitted belt guard.(belt drive models) or pump shroud (direct drive models).
- Never operate the unit with damaged or exposed electrical wiring.
- Do not alter, adjust or remove any components on the unit without technical support.
- Whenever transporting an air compressor, ensure all air is drained from the air receiver. There should be NO residual air pressure in the air receiver.

MAINTENANCE INSTRUCTIONS

- Check that fuses or circuit breakers correspond to motor rating. In case of 415-Volt units, check rotation as indicated by arrow attached to unit. On 240-Volt units, avoid using extension leads as they could cause voltage drop and power loss to motor. If extension is to be used, please follow the table below.

TABLE 1.

KW	HP	VOLTS	RECOMMENDED WIRE SIZE
1.65	2.25	240	HEAVY DUTY, 1.5MM SQUARE WIRE (MAX LENGTH 20 M)
2.20	3.00	240	HEAVY DUTY, 1.5MM SQUARE WIRE (MAX LENGTH 10 M)

- Oil level must be obtained at centre of oil sight glass. Do not overfill as this could cause excessive oil out going from the crank case breather.
- Oil is to be replaced every 1000 working hours or on a six (6) monthly basis.

RECOMMENDED OIL:

- PILOT PCO-40G or equivalent (Stationary models).
- PILOT PCO-30G or equivalent (Portable models).

Note: In humid and/or very low duty cycle environments, condensate may collect in the sump. Under these conditions, it is a requirement that the operator drain the residual water from the sump on a regular basis and/or change the oil more frequently than recommended above.

- Air filter element should be cleaned periodically and replaced every 500 working hours. (Under normal environmental conditions).
- Routine maintenance should be performed on at least a six (6) monthly basis.
- Condensation must be drained from air receiver at least weekly.
- Unit must be kept clean to allow proper cooling to take effect. Special care should be taken to clean the crankcase breather in order to allow proper crankcase breathing.
- Whenever attempting to carry out any maintenance to compressors, isolate power and release all pressure from receiver.
- For information regarding spare parts and/or service, please always quote model and serial number.
- **PLEASE KEEP THIS INFORMATION NEAR MACHINE, SO IT CAN BE READ BY ANYONE ATTEMPTING PREVENTATIVE MAINTENANCE.**

NOTE:

DO NOT BOLT COMPRESSOR DIRECTLY ONTO FLOOR. THIS MAY CAUSE CRACKS IN THE AIR RECEIVER. PLACE COMPRESSOR ON THE RUBBER VIBRATION PADS PROVIDED. IF THE COMPRESSOR MUST BE BOLTED, ENSURE RUBBER VIBRATION PADS ARE IN PLACE AND FASTEN, LEAVING A GAP BETWEEN BOLT HEAD OR NUT AND COMPRESSOR FOOT TO AVOID ANY METAL TO METAL CONTACT.

COMPRESSOR COMPONENT DESCRIPTIONS

- **PRESSURE SWITCH:** This switch is located on the top of the air receiver and functions as a manual on/off switch in addition to automatically stopping and starting the compressor at factory pre-set pressures (electric models only).
- **PRESSURE GAUGE:** The Pressure Gauge is located on the air receiver and indicates the pressure held in both PSI and KPA.
- **SAFETY VALVE:** The Safety Valve is located on the air receiver and is designed to release pressure in the event of a pressure switch failure.
- **OVERLOAD PROTECTION:** Electric models are fitted with an overload protector, to protect the motor in the event of an over temperature condition. These reset buttons are located either on the pressure switch or the motor itself.
- **CHECK VALVE:** The Check Valve is located at the junction of the pump discharge pipe and the air receiver. The check valve prevents air pressure from returning from the air receiver to the pump.
- **EASY START VALVE:** (Petrol/Diesel models only) The Easy Start Valve is located on the check valve for portable units and on the compressor platform for stationary units. This valve should be opened for ease of starting of the engine and closed when running for normal operation.
- **RECEIVER DRAIN:** The Receiver Drain is located at the underside of the air receiver and is used for draining condensate from the receiver.
- **OIL SIGHT GLASS:** The Oil Sight Glass is located on the side of the compressor pump (opposite the flywheel) and is used for examining the oil level of the unit.

THREE YEAR PUMP WARRANTY INFORMATION

Models covered the three year pump warranty are listed below:

- TRADEMASTER SERIES UNITS
- CLASSIC K SERIES UNITS
- PETROL INDUSTRIAL SERIES UNITS
- THREE PHASE INDUSTRIAL SERIES UNITS

Details are as outlined below:

- **Extended three year warranty applied to compressor pump only and excludes all other components the unit. All other components are covered as outlined in Warranty Information overleaf.**
- **Warranty conditions are as per standard conditions as listed in Warranty information overleaf.**

MACHINERYHOUSE

WARRANTY INFORMATION

We warrant to the first owner of the unit described in the registration form below that we will replace parts, free of charge, or if we consider repair sufficient, we repair free of charge any part proved defective as to material or workmanship under normal use or service, for a period of twelve (12) months from date of purchase.

Parts repaired or replaced without charge under warranty are warranted only during the balance of the new warranty period. All defective parts under the warranty become the property of PILOT AIR COMPRESSORS PTY LTD.

This warranty however, shall not apply to the following parts or conditions:

- **Any PILOT AIR product or part which has been subject to misuse, negligence, accidental damage, improper or inadequate use, inadequate maintenance, or improper storage.**
- **Repairs rendered necessary or arising from the use of other than genuine PILOT AIR parts.**
- **Normal maintenance items including but not limited to valves, piston rings etc.**
- **Deterioration of any item due to normal use, fair wear and tear and exposure unless due to any defect in material or workmanship.**
- **Any work or adjustment performed by other than an authorised PILOT AIR agent or damages resulting therefrom.**
- **Damages resulting from the use of the unit for purpose other than which it is intended; from the unit being operated with essential parts or accessories removed; from the unit being operated under unusual conditions or continuously under excessive load.**
- **Should the serial/model label be removed.**

Warranty repairs on all 240 Volt and portable units shall be on a back to base basis. The replacement or repair of any defective parts, or correction of operating faults, under this warranty is made only after PILOT AIR COMPRESSORS PTY LTD or their authorised representative have examined the unit to their satisfaction. The liability of PILOT AIR COMPRESSORS PTY LTD shall be limited to the replacement or the repair of the goods as the case may require.

WARRANTY INFORMATION CARD.

OWNERS NAME _____

ADDRESS _____

MODEL _____ SERIAL NUMBER _____

DATE PURCHASED _____

DEALERS NAME _____

DEALERS INVOICE NUMBER _____

**PLEASE PRESENT THIS CARD ALONG WITH PURCHASE
INVOICE WHEN REQUESTING WARRANTY SERVICE.**

K25 PUMP

