




**1. Buttons and Switches on the Controller Panel:**




## PMNC-PUNCHING TABLE NC STOPPER


F1: Array



F2: Customize



F3: Single



F4: Prev Page

F5: Save

F6: Next Page

F7: Calibrate

F8: Prev Program

F9: Next Program

AUTO: Stopper+Punch

TEST: Stopper Only

PUNCH: Move Stopper

Manually, Punch Only

- **Emergency Stop:** Stop the machine in emergency.
- **PUMP ON:** start the motor
- **PUMP OFF:** stop the motor
- **NORMAL/JOG** switch: switch between cylinder normal movement and jog movement (refer also to Operation Modes)
- **AUTO/TEST/PUNCH** switch (refer to section below on Operation Modes)
- **START:** Run programs. Light flashes during program execution. If any of the select switches is turned before the end of program, the program stops.

## **2. Operation Modes:**

**AUTO:** Run the program and execute punch. The Stoppers moves automatically to next position after each hole is punched.

**TEST:** Run the program without punching. The stoppers moves automatically to next position each time the foot paddle is pressed, but the cylinder does not punch the hole. Use this mode to test the correctness of the program.

**PUNCH+NORMAL:** Execute punch without using the NC stoppers. This is like using the normal PM machine to punch holes. Use this mode to check the correct setting of the stroke limit switches. In the mode, the stoppers can be moved by the cursor keys, but cannot run programs.

**PUNCH+JOE:** The cylinder moves down when the foot paddle is pressed, but does not move back up when the paddle is released. Use this mode for checking the punch alignment each time the tool is changed. The NC stopper does not function in this mode.

Note: in AUTO and TEST modes, the NORMAL+JOE is non-functional. The cylinder moves only as Normal mode and not Jog mode.

### **3. Operation Sequence**

- 1) Turn on power. Be sure the emergency button is released. Screen will be on after a brief self-check.
- 2) Be sure the stripper is closed.
- 3) Press Pump ON to start the motor
- 4) Turn to PUNCH+NORMAL mode and check the limit switch for cylinder stroke adjustment is set correctly.
- 5) Turn to AUTO mode. The screen will prompt you for calibration
- 6) Press F6 (shift+F3) to calibrate the stoppers
- 7) After calibration, the screen switches to the function mode.
- 8) Press one of three type of programs (F1, F2, or F3)
- 9) In the Array or Cust program screen, press the program number to call out the previously stored program, or use F8/F9 to move up/down the program numbers.
- 10) In the desired program, enter the values for each of the parameter fields. Use ESC and Enter keys to move up/down the parameter fields.
- 11) Press F5 to store the parameter fields.
- 12) You may switch to TEST mode to test run the program, or in AUTO mode press START to run the program and execute punching. The stoppers move to the first hole of the program.
- 13) If in TEST mode, press the foot paddle to move to next hole. If in AUTO mode, press the foot paddle to execute the punch. After the hole punching is completed, the stopper automatically moves to the next hole (if any).

### **4. Calibration of NC stopper**

Each time the power of the machine is turn on, you will need to first calibrate the NC stopper. Press F6 (shift+F3) and the NC stopper will calibrate itself. When the NC stoppers stops and screen switch to Function screen, calibration is completed. If problem occurs, Err. 23 appears (refer also to section "Error Messages"). Press F7 (Shift+2) at anytime to enter the calibration screen again.

## 1. Function Screen

There are 3 types of programs available in the controller. Array program is array program of holes. Up to 99 Array programs can be stored in the controller. Cust program is a series of customized holes (up to 20 holes in one program). Up to 25 Cust programs can be stored in the controller. Single program is single hole punching. It is useful to move the stoppers to a precise desired position. Single program cannot be stored.

		<b>F 4 : SET</b>
<b>F1</b>	<b>F2</b>	<b>F3</b>
<b>Array</b>	<b>Cust</b>	<b>Single</b>

Press F1 to enter the Array Program Screen


Press F2 to enter the Cust Program Screen

Press F3 to enter the Single Program Screen

Press F4 (Shift+F1) to enter the Setting Screen (password required)

You can press F1, F2, F3 at anytime to enter the program screens.

F1:Array



F1: ARRAY	<input type="text" value="00"/>
X: <input type="text" value="0000.00"/>	Y: <input type="text" value="0000.00"/>
I: <input type="text" value="000.00"/>	J: <input type="text" value="000.00"/>
M: <input type="text" value="0"/>	N: <input type="text" value="0"/>
X: 0000.00	Y: 0000.00

Use the ESC and Enter key to move to previous and next parameter field and enter the value with the number pad. The allowed number range is shown while entering the value.

Array Number (1 to 99) up to 99 sets of array program can be stored. Call out any previously stored program by enter the array number.

F8 (Shift+ESC) : Previous Array program number

F9 (Shift+enter) : Next Array program number.

X : X-coordinates of the first hole

Y : Y-coordinates of the first hole

I : distance to the next hole in X direction

J : distance to the next hole in Y direction

M : number of holes in X direction


N : number of holes in X direction

X and Y in last line shows the current position of the NC stoppers

F5 : Save the entry. If switch to other screen without press F5 first, then the entered values are not saved.

Press START to execute the program, NC stopper moves to first hole.

F2:Customize



F2: CUST	00	END	00
1X:	0000.00	Y:	0000.00
2X:	0000.00	Y:	0000.00
3X:	0000.00	Y:	0000.00
4X:	0000.00	Y:	0000.00

Use the ESC and Enter key to move to previous and next parameter field and enter the value with the number pad. The allowed number range is shown while entering the value.

CUST Number (1 to 25) up to 25 sets of array program can be stored.

Call out any previously stored program by enter the array number.

F8 (Shift+ESC) : Previous CUST program number

F9 (Shift+enter) : Next CUST program number.

1 X , Y : Coordinate of the first hole

2 X , Y : Coordinate of the 2nd hole

....

20 X , Y : Coordinate of the first hole

Up to 20 holes can be stored in one Cust program, but only coordinates of 4 holes are shown on the screen at one time.

F6 (Shift+F3) : Next Page (next 4 holes)

F4 (Shift+F1) : Previous Page (previous 4 holes)


END: enter the value indicate the number of holes in this Cust program.

Example: END=3, then only the first 3 holes (1X,1Y), (2X,2Y), (3X,3Y) will be punched when running this program.

F5 : Save the entry. If switch to other screen without press F5 first, then the entered values are not saved.

Press START to execute the program, NC stopper moves to first hole.

F3:Single



F3: SINGLE	
X: <input type="text" value="0000.00"/>	Y: <input type="text" value="0000.00"/>
X: 0000.00	Y: 0000.00

Use the ESC and Enter key to move to previous and next parameter field and enter the value with the number pad. The allowed number range is shown while entering the value.


X , Y : Coordinate of the hole

Note: X and Y in last line shows the current position of the NC stoppers

Press START to execute the program, NC stopper moves to hole.



## 6. Manually move the NC stoppers



Turn to PUNCH mode and the screen switches to the manual mode. Use the cursor to move the stoppers. Current position of the stopper is shown on screen.

- F1 : Move the X-stopper to left ( X-Axis value increase )
- F2 : Move the Y-stopper toward you ( Y-Axis value decrease )
- F3 : Move the X-stopper to right ( X-Axis value decrease )
- F5 (Shift+F2) : Move the Y-stopper away from you ( Y-Axis value increase )

X , Y : Current position of the NC stoppers

## 7. Setting Screen

**WARNING:** incorrect entry of these setting parameters may result to malfunctioning of the table or even damage of the table. The setting are preset in factory before shipment, and should be changed only by qualified maintenance/service personnel.

- I) If the origin point is off, or you need to adjust the software protection of X and Y travel range (min and max of X and Y table travel), you will need to change the parameters in the travel setting screen.

To enter the setting screen (Password Protected), press F4 and you will be prompted for password. Enter **7777** and following setting screen appears:

<b>F4: SET</b>			
<b>X-s</b>	<input type="text" value="####.#"/>	<b>Y-s</b>	<input type="text" value="###.##"/>
<b>Mi</b>	<input type="text" value="###.##"/>	<b>Mi</b>	<input type="text" value="###.##"/>
<b>Ma</b>	<input type="text" value="####.##"/>	<b>Ma</b>	<input type="text" value="####.##"/>

F8: previous setting page

F9: next setting page

X-s : Set the value of the X stopper after calibration.

Y-s : Set the value of the Y stopper after calibration.

Mi(X)/Mi(Y) : Set the minimum value of X and Y stopper travel range.

Ma(X)/Ma(Y) : Set the maximum value of X and Y stopper travel range

These Min/Max values are also call the software travel range.

II) To enter the motor parameter setting screen **press F4** and you will be prompted for password. Enter **6666** and following setting screen appears:

<b>F4: SET</b>	
Tolerance value:	<input type="text" value="#.##"/>
Motor frequency:	<input type="text" value="#####"/>
Accel/Decel speed:	<input type="text" value="###"/>


Tolerance level: this is the tolerance level allowed for the difference between the programmed value compared to the actual value. If the difference is greater than the tolerance level, then the set value, the program stops and the Error screen is shown.

Motor Frequency: Set the motor frequency. (unit: pps)

Acceleration/Deceleration Time: Set the motor acceleration/deceleration time. (unit: ms)


Press F4 to exit the setting screen.

## 8. EURROR MESSAGE




Error 11: When the movement of the cylinder is required but the pump is not turned on.

Solution: Press “pump on” to turn on pump.



Error 12: Before execute a program, the cylinder needs to be at the top position. If the cylinder is not in top position (e.g. cylinder moved down in JOG mode) and the “Start” is pressed, Err 12 is shown.

Solution: Turn the switch to “punch” to move the cylinder to top position.




Error 13: The Stripper is open. For safety reason, the machine will not move when the stripper is open.

Solution: close the stripper.



Error 14: In Array mode, the value of M and N cannot be 0.

Solution: Press F1 to Array screen, enter values greater than 1 for M and N parameter.




Error 15: In Custom mode, the value of the END cannot be 0.

Solution: Press F2 to CUST screen, enter values greater than 1 for END parameter.




Error 21: The Stopper has reached the Hardware Min or Max travel range allowed (set by proximity switches).

Solution: Select PUNCH mode. Use cursor key (F1, F3, F2, F5) to move the NC stopper away from the Min or Max position.




Error 22: The Stopper has reached the software Min or Max travel range allowed (set by Mi/Ma parameters in SET screen).

Solution: Select PUNCH mode. Use cursor key (F1, F3, F2, F5) to move the NC stopper away from the Min or Max position.



Error 23: In Calibration, the NC stopper is not able to find the origin position after certain time.

Solution: check the origin proximity switch to see if the contact piece is positioned too far or if the switch is broken. Turn power off then turn on power again to reset the controller and try to calibrate again. If problem persists, contract Sunrise agent for repair.



Error 24: During running an ARRAY program, the difference between the actual position and programmed position is greater than the tolerance level (set in Setting screen).

Solution: Check if there is any obstruction on the NC stopper to prevent it from moving smoothly (e.g. stopper need to push too heavy a plate). Press F1 to leave the error. Note: if the tolerance level is set too small, this error may happen more frequently.



Error 25: During running an CUST program, the difference between the actual position and programmed position is greater than the tolerance level (set in Setting screen).

Solution: Check if there is any obstruction on the NC stopper to prevent it from moving smoothly (e.g. stopper need to push too heavy a plate).

Press F2 to leave the error. Note: if the tolerance level is set too small, this error may happen more frequently.



Error 26: During running a SINGLE program, the difference between the actual position and programmed position is greater than the tolerance level (set in Setting screen).

Solution: Check if there is any obstruction on the NC stopper to prevent it from moving smoothly (e.g. stopper need to push too heavy a plate).

Press F3 to leave the error. Note: if the tolerance level is set too small, this error may happen more frequently.