



Established 1930
Distributors of new & used workshop Equipment

S797

MRMS2550 x 190

PLATE ROLLS


PARTS MANUAL

30/2/08



sahinler
METAL MAKİNE ENDÜSTRİ A.Ş.

USER'S MANUAL
MODEL MRM-S 190
ASSYMETRICAL 3 ROLLS
PLATE BENDING MACHINE



İzmir Yolu 22.km Mümin Gencoğlu Cad. 16285 BURSA / TURKEY

Tel: +90-224-4700158 (6 lines pbx)

Fax: +90-224-4700770

Web: www.sahinlermetal.com

Email: info@sahinlermetal.com

Spare parts & service: service@sahinlermetal.com



sahinler
METAL MAKİNE ENDÜSTRİ A.Ş.



CE DECLARATION

We as

ŞAHİNLER METAL MAKİNE END. A.Ş.
İzmir Yolu 22.km
Mümin Gençoğlu Caddesi
Bursa / TÜRKİYE

confirm that the machine

MRM-S 190

Serial Number :
Production Year :

complies with

EC MACHINES DIRECTIVE 98 / 37 / EWG / CEE
replaced with EC-Directives 91 / 368 / EWG and
93 / 44 / EWG and
93 / 68 / CEE
EC-Low Voltage 73 / 23 / EWG
EC - Noise Level Directives 86 / 188 / EWG

and the machine also harmonized with the standards

DIN EN 60204 Part 1

Name : Mustafa PINARBAŞI
Position : Production Director

BURSA, on.....

SAHİNLER
METAL MAKİNE ENDÜSTRİ A.Ş.
İzmir Yolu 22.km - Mümin Gençoğlu Cd.
Bursa / TÜRKİYE

CONTENTS	Page
<i>General Notes</i>	1 – 2
<i>General Warranty Terms</i>	3
<i>Transport and Lifting</i>	4
<i>Technical Properties</i>	5
<i>Main Dimensions</i>	6
<i>Foundation Plan</i>	7
<i>Explanation Of Foundation Plan</i>	8
<i>Safety Directives</i>	9 – 13
<i>Electrical Connections</i>	14
<i>Operating Instruction</i>	15
<i>Bending Operation</i>	16 – 19
<i>Opening the Up Roll</i>	20
<i>Maintenance</i>	21
<i>Main Parts Schema</i>	22
<i>List of the Parts</i>	23
<i>Electrical Schemas</i>	24
ANNEX	
<i>Digital Read-Out</i>	

GENERAL NOTES

1. Introduction

Thank you for choosing a Şahinler Sheet / Metal Working Machine. We are proud to have you in our long list of satisfied customers all over the world.

This User's Manual is absolutely for your safety and is essential for the machine to have a long production life. As long as you keep up with our Manual you will be able to run your machine smoothly and safely. Keep in mind that the machine is designed absolutely to perform maximum safety and for efficient working.

In this Manual you can find instructions and information about:

- Correct installations of the machine
- Description of the functional parts of the machine
- Set-up and start-up adjustments
- Correct standard and scheduled maintenance
- Simple safety regulations and accident prevention.

Therefore, as far as the user's safety is concerned, in this handbook the possible risks connected with machine operation are pointed out as follows:



Attention: Showing the risks of accident, if instructions are not followed.



Warning: Showing the probable damages to the machine or equipment, if the instructions are not strictly followed.



Note: It gives useful information.

It is certainly necessary that the operator should read and understand all the **Attention, Warning, Note** specified in this Manual before starting with operation of the machine and before any lubrication or maintenance intervention

On all steps of installation, operation and maintenance safety must be your first concern for the protection of yourself, other users and the service of the machine. In case of any failure please first refer to this Manual, and then if a solution cannot be found contact first of all the distributor where you purchased our product. Do not forget to refer to the drawings and the numbers for any spare part needed or to define any problem. Make sure you have the serial number and production year of the machine.

Our technical staff will make their best to help you in the most convenient way.

2. Transport

As soon as you receive the machine, check for any visible transport damages. Should there be any visible damages; report it straight away to the transporter company and of course Şahinler Metal Mak. End. A.Ş. or your supplier.

Remove any protective crates around the machine and read the instructions on related chapters of this Manual carefully to set up the machine. If the machine is damaged while transport, immediately take some photographs for insurance claims.

Take precautions while loading / unloading or moving the machine to avoid any injuries. Refer also to related chapter of this Manual for the best way of handling the machine.

3. Electrical Information

All necessary connection procedure can be found on this Manual. Do not try to connect the machine before reading these procedures and fully understanding the drawings. For any unclear matters get in touch with Şahinler Metal Mak. End. A.Ş. or any of the Şahinler distributors. Have the machine connected by a qualified electric technician. For, as we made clear in the "general conditions of guarantee", under no circumstances installing mistakes, including electrical connection mistake, can not be covered by guarantee agreement. Always turn off power before making any connections or disconnecting the machine.

4. Maintenance

Your machine is designed and produced to work efficiently and smoothly. To achieve this you should also take care while operating the machine. Regard Maintenance sections to have the longest life from your machine. Try and use original spare parts where necessary and most importantly do not overload the machine or do not make any unauthorized modifications.

5. Safety

Take all precautions possible to avoid any personal injury while using the machine. Keep in mind to protect the third party people around the machine. Refer to safety directives.

GENERAL WARRANTY TERMS


- Your machine is covered by manufacturer's guarantee for a period of 12 months from the date of purchase against manufacture defects. The warranty period does not exceed 18 months from the date of delivery from the manufacturer's factory.
- Warranty covers only manufacture defective parts and / or components that are reported as "defective" by a Sahinler Technician or the Agent Technician and must be reported to Sahinler in writing by fax or email.
- The manufacturer is responsible for the supply of free of charge spares only and cannot be held responsible for loss of work.
- Shipping and customs fees for the spare part must be paid by the end-user.
- If a technician travel is necessary Sahinler will not charge for labor and workmanship costs but the customer must pay traveling and accommodation charges.
- A Warranty claim does not relieve the Customer from payment obligations.
- The Customer can not ask or demand any reimbursement of damage nor the Customer will have the right to extend or delay payment obligations nor the cancellation of order and the refunding of damages as the guarantee is given for the defective parts of the machine and not for the job.




Note: All warranty claims must be applied with the Model, Serial Number and the Manufacture Year of the machine.

TRANSPORT AND LIFTING OF THE MACHINE


Use necessary cranes and lift as shown. Please take extra care during lifting and moving. If necessary consult with specialized companies for lifting.




FALSE



FALSE



TRUE



TRUE

APPROX MACHINES WEIGHT;
MRM-S 1050x190 2450 kg
MRM-S 1550x190 2750 kg
MRM-S 2050x190 3100 kg
MRM-S 2550x190 3400 kg
MRM-S 3050x190 3750 kg

OPENING THE PACKAGE

If any visible damage exist on the machine when you receive the machine immediately informs the dealer or manufacturer. Also never forget to state the visible damage on transport documents.

The packing material is completely safe and do not consist any environmentally dangerous articles. However they must be kept out reach of children as some nylon products in packing may cause suffocation if used as a toy etc.



TECHNICAL PROPERTIES

The MRM-S Model Mechanical Three Roll Benders have these specifications:

Model		MRM-S 1050x190	MRM-S 1550x190	MRM-S 2050x190	MRM-S 2550x190	MRM-S 3050x190
Pre-bending	mm	9	8	6	5	3
Bending	mm	10	9	7	6	4
Roll Diameters	mm	190	190	190	190	190
Min. Internal Diameter	mm	285	285	285	285	285
Main Motor power	Kw	4	4	4	4	4
Back Roll Motor	Kw	1,5	1,5	1,5	1,5	1,5
Useful length	mm	1050	1550	2050	2550	3050
Length	mm.	3200	3700	4200	4700	5200
Width	mm	950	950	950	950	950
Height	mm	1300	1300	1300	1300	1300
Weight	Kg	2450	2750	3100	3400	3750



Note : Machine dimensions are approximate

TECHNICAL SPECIFICATIONS AND STANDARD EQUIPMENTS

- Two rolls powered by a single chain or belt driven worm type gearbox and gear system
- SAE 1050 Quality certificated steel rolls with high tensile strength
- Steel welded main frames
- Mobile control panel
- Conical bending device
- Central lubrication
- Precision bending with brake motor
- Motorised adjustment of back roll
- Worldwide available components used in production (Telemecanique, Siemens for electric)
- User manual book
- Built according to EC safety directives (CE – Mark)

OPTIONAL ACCESSORIES


- Digital read-out for rear roll
- Induction hardened rolls
- Extended roll shafts for profile and pipe bending
- Profile and section bending rolls





Warning: Do not feed profiles having a higher thickness than specified for the capacity of the machine. Do not feed more than one piece at a time. Do not use the machine for any other job the one for which it has been designed.

MAIN DIEMENSION OF THE MACHINE

Model	Useful Length	A mm.	B mm.	C mm.
MRM-S 1050x190	1000	3200	1300	950
MRM-S 1550x190	1500	3700	1300	950
MRM-S 2050x190	2000	4200	1300	950
MRM-S 2550x190	2500	4700	1300	950
MRM-S 3050x190	3000	5200	1300	950




MRM-S 190 FOUNDATION PLAN



Y DETAYI Y DETAIL





MODEL	(L)
MRM-S 1050 x 190	2750 mm
MRM-S 1550 x 190	3250 mm
MRM-S 2050 x 190	3750 mm
MRM-S 2550 x 190	4250 mm
MRM-S 3050 x 190	4750 mm



EXPLANATION OF FOUNDATION PLAN

On attached pages you can find foundation plan of the machine. For operation the machine must be placed in a pit as shown and must be bolted to the ground. For bolting refer to front page.

After placing the machine make sure all areas of the machine is flat and check parallelism of the machine periodically by a water gauge.



SAFETY DIRECTIVES

The ŞAHİNLER A.Ş. three-roll plate bending machine is supplied with necessary guards to protect from injuries by worm-type gearbox and other gears. The only other area which needs to be carefully monitored during use is the rotational area of the rolls.

Also abuses and misuses risk the following:

- > Serious injury of the user
- > Serious damage to the machine

All persons who are in of the machine should carefully read and fully understand this manual for the benefit of themselves.

This is for your safety !




Attention:

- > Never try to bend very hard or fragile material on the machine (e.g. hard steel, glass)
- > Any modification on the machine without written confirmation from the manufacturer is strictly forbidden as such changes in the machine can cause unintended damages and injuries.
- > All orders and advises in this machine should be strictly obeyed for a safe working environment.

DANGER ZONES

The below shown danger zones must be kept clear during operation



NOISE: The noise of the machine is about <70 dB.



EXPLANATION FOR OPERATOR

Operator under age of 16 years to operate the machine is strictly forbidden (EC-Directive). The operator of the machine should carefully read this manual and understand the danger he might be in if he misuses or abuses the machine. If any part of this manual is unreadable or illegible please contact to the dealer and manufacturer

The owner of the machine should be responsible for operating the machine with qualified personnel.

PERSONAL PROTECTION

Gloves and safety glasses and safety cap are recommended during operator.




Attention:

- No material should be fed if the machine is running.
- All emergency stop must be easily accessible.
- The user must be careful for third persons entering the operation area of the machine.



Note : If any labels are lost or unreadable contact the manufacturer for new supplies.

WORKING AREA OF THE MACHINE



Attention: Before the first use of the machine always check this list carefully for a safe start.

1. Check the emergency stop button on the command panel
2. Make sure that the security wire around the machine is free
3. Check for visible oil leak
4. Control of the buttons on the command panel

SAFETY AND ACCIDENT PREVENTION INSTRUCTIONS


General Safety Instructions

Following instructions are meant for the operator of the machine and it is the End-User's responsibility to make sure the operator reads and understands the following and the User's Manual for safe operation.

- Read the User's manual before operating the machine.
- Never touch rotating or moving parts.
- Always inform electric faults to electric technicians.
- Keep your working dress or long hair or necklace etc away from rotating parts.
- Make sure you know the position of Emergency Stop Buttons on the machine.
- Switch off the machine when **NOT** working.
- Work with necessary safety clothes if necessary (safety shoes, glasses , earplugs etc).
- Control the Safety features before working and ensure they are working properly.
- See and understand Safety Labels on the machine.
- Perform periodic maintenance.
- **DO NOT** overload the machine.
- If you see abnormal behavior of the machine, stop the machine and inform your supervisor immediately.
- Be careful of other people around the machine during operation.
- Never modify electric unit.
- Never remove any mechanic or electronic safety features from the machine.
- Be extremely careful during transport or re-placement of the machine and follow transport instructions in the manual to safety handle the machine.

MOTORISED BACKROLL SAFETY SWITCH


The motorized back roll has a safety switch. When the roll is at its lowest point the switch will stop the motor.





EXPLANATION FOR SAFETY SWITCH

The machine has been equipped with a security switch and wire for the operators safety. When the safety wire is pushed it pulls the below shown ring this act as emergency stop and stops all machine activity.

To restart pull the blue knob (shown by ① in fig.1) while pulling the safety wire when engaged you should see green (shown by ② in fig.2) line under the blue knob. Now you can restart the machine from control panel.



Safety switch's on and off positions as given below.



The safety wire comes unassembled for packing reasons and must be assembled by the customer as shown above to completely surround the machine




Figure 4



Attention:

The safety wire is an important safety measure and must never be removed while the machine is setup. It should be only removed for transport purposes.

While assembling it is important to fit the wire to the safety switch lock securely as shown below.




Figure 5

ELECTRICAL CONNECTIONS



Warning :

All electrical connections must be performed and completed by a qualified electric technician in order to minimize chance of personnel injury or damage caused by wrong connection.

The cable must be directly connected to the machine. No intermediates should be used. The following pages contain the necessary diagram of electrical connections.

Ensure that the Electric Net is capable of loading up to V. Double-check the grounding for a safe operation. (look at electricity plan)

ROTATION OF MOTOR

After all the electrics have been completed, start the machine as below and check the rotationary axis of the motor.

- Bring Main Switch to Pos 1
- Bring Key Switch to Pos 1
- Push the foot pedal
- Check the rotation direction axis of the motor


Reverse connect the electrics by qualified electric technician to achieve right rotation direction.



Note : When you push the button of up the roll on the commander control panel, if rolls are moving up (moving reverse position) this means that motor is moving the reverse position. We advise to change the electric cable connecting points.

INSTALLATION FIGURE

Connection of operation plug to machine;



OPERATING INSTRUCTIONS

First Start-Up



- When you see the Power On Indicator press the Start Button. The motor should start up and after a few seconds you should hear the machine running
- Test the movements of the machine by pressing rotation and up-down buttons

Normal Operation

Before starting to operate the machine, when you must to read electric panel's explanation.

A diagram of the Operator's Panel is given below;

1. Power On Key Switch – Safety Key Switch. When the machine is not in use please remove the key to avoid unauthorized operation
2. Start button – To start main motor
3. Power on indicator – When on this indicates the machine Main Power Switch is on and ready to start
4. Emergency stop
5. Rolls rotation – Right
6. Rolls rotation – Left
7. Back roll – Down
8. Back roll – Up
9. Digital display (optional)



- A. Back Roll (Bend Roll)
- B. Lower Roll (Pinch Roll)
- C. Top Roll

BENDING OPERATIONS

3 ROLL BENDING PRINCIPLES

Because of the heavy materials involved in bending, it must be done by qualified personnel who have experience on such machines. Each step of the bending and pre-bending or conical bending must be done very carefully. Remember that you can always make the radius tighter by bending a little more but once you bend it too much there is no way of turning back.



Note: Before operating the machine, be sure that this manual is thoroughly read and understood by the personnel who will directly operate the machine and others concerned with it.


PRE-BENDING OPERATION

Pre-bending is the operation where the edges of the material is bent to the same radius of the end radius. This is used to get best results in full circle bending (i.e. pipe making)or in operations where there must not be any flat edges. According to the final radius to make the finished material very good.


The pre-bending process is also different compared to 3 roll bending machines. The following steps must be taken to make a pre-bending.

Before operation:


1. Clean the material and the rolls from dust, or grease
2. Make sure there are no chips or flame cutting left-over on the edges of the material
3. Keep in mind that if the material is cut by flame that side will be harder than the other side
4. Check the surface of the material carefully make sure its flat
5. It's a good idea to have template of the required radius when making a bend. To make a template cut a hard cardboard or carton piece with the necessary radius
6. Always work in the center of the rolls as shown below.




TRUE



TRUE



FALSE



FALSE

Sheet Bending Position

Figure 1

Top roll and lower roll in a flat position.




Figure 1

Figure 3

Reverse the sheet and place for second pre-bending.




Figure 3

Figure 5

Roll until required diameter is achieved.




Figure 5

Figure 2

Move the back roll up to complete the pre-bending




Figure 2

Figure 4

Move the back roll up to complete Pre-bending




Figure 4

Figure 6

The finish operation shown as below figure 6




Figure 6



Note: That the material will progressively harden with each pass.



Note: If you are working with stainless steel it is important to finish the job in a few passes. Because the work hardens and it progressively hardens after each pass.

CONICAL BENDING

To make the conic bending operation in the machine, the down roll must be in oblique position. Please follow these instructions step by step.

- Down roll must be in bottom position
- At the back of the machine, near the roll there must be a cover in it, please remove this cover.
- Roll must be in oblique position
- Opening roll must be in oblique position too to make this roll must be in up position
- To adjust this roll please take off the connections under the cover and it must be moved into oblique position (like down rollers)
- Now two rolls are in oblique position and machine is ready for conic bending

Please replace the sheet in the ready (for conic bending) machine and replace the conic support bars behind the sheet now you can make conical bending.



Attention : Be sure to clean any oil or grease put on the rolls before operation. If you don't work with lubrication or lubrication deficiency we are not responsible for lubrication deficiency or any damages at last.





Note: When bending conical the overall max. thickness capacity decreases by 25 %



Note: When cone bending, the thickness and width capacities of the machine are reduced. Check with the distributor or manufacturer for your requirements.



Because of the extra resistance forces on the rolls while making conical bending the capacity of the machine must be accepted half as usual therefore the max. bending thickness must be reduced to half in conical bends. The conical bending is done by using the attachment on right side of the machine and the tilting of the roll. Please refer to the drawing for a better idea of a conical bend.




DETAIL 1

- Loosen bolts A
- Detach B connection
- Use the lift motor to tilt the bending roll D

Straightening the D Roll

To straighten the roll D after conical bending you must put straight materials (E) between rolls F and D and reversing the operation above

OPENING THE TOP ROLL



Mechanical
Lock

Figure – 1





Figure – 2



Safety
Microswitch

Figure – 3

Opening the top roll is easy and safe. Once the top roll is open the machine will not function. There is a safety microswitch (Figure – 3) that prevents the machine from operating while the top roll is open.

1. Release the mechanical lock to move the handle on top roll (Figure – 1)
2. Move the handle as far as you can and see that the roll can move in the housing (Figure – 2)
3. Pull the top roll out (Figure – 3)
4. Reverse above steps to close the top roll and make sure the mechanical lock is secure.



Warning:

Do **NOT** modify this safety device. **NEVER** operate any function of the machine while the top roll is open.

MAINTENANCE

PERIODIC CONTROLS


The rolls of the machine must **NEVER** be greased or lubricated. Because, then the rolls will slip the material and will not bend. Always keep the rolls clean and free from grease or any lubricant. Also make sure that the material is free from grease and dirt.

These points must be greased periodically at least once a month or more if daily usage exceeds 8 hours a day. Note that some of these points are actually inside the machine cover and the front cover must be removed in order to reach them. Any standard commercial grease can be used for lubrication.

NUMBER	PERIOD	WHAT TO DO
1- Gear system	Once a month	Grease
2- Gearbox	Once a year	Oil

REDUCTION GEARBOX MAINTENANCE


The reduction gearbox of the machine is inside the front cover and is maintenance free. Only you should control it periodically and tighten the bolts fixing it to motor and to the frame, if necessary.



LUBRICATION PLAN

For efficient working with the machine the above marked (1 and 2) parts must be greased at least once a week. Also the (x) marked lubrication pump oil level must be controlled and re-filled if necessary. We recommend Mobil Vectra 2.





The lever on this pump should be pulled up once and it will go down slowly by itself to lubricate. Then it must be pulled up again.






LISTS OF THE PARTS


Assembly No	Part Identification	Assembly No	Part Identification
1	Lower Frame	33	Lifting Shaft
2	Motor side Frame	34	Lifting Shaft
3	Drop end Frame	35	Top Roll Joint
4	Top roll	36	Top roll Bushing
5	Pinch roll	37	Top roll Gear
6	Back roll	38	Top Roll Gear Flange
7	Main Profile	39	Top roll Tensioning
8	Tension Profile	40	Top roll Bearing
9	Back Roll Bushing	41	Bearing Flange
10	V-Belt Flywheel	42	Bolt
11	Front roll motor pulley	43	Bottom Roll Bushing
12	Back roll motor	44	Bottom roll Power Gear
13	Bottom roll Bushing	45	Bottom roll Chain Gear
14	Bottom roll lifting wheel	46	Double line Chain
15	Top roll Bushing	47	Idle Roll Bushing
16	Top Roll Chrome Bushing	48	Reduction Gearbox Tensioning
17	Flange	49	Bolt
18	Lifting Shaft	50	Front Cover
19	Lifting Shaft	51	Chain Gear
20	Gear	52	Reduction Gearbox
21	Gear Box Cover	53	V-Belt Flywheel
22	Spacer	54	Power Motor Pulley
23	Gear Wheel	55	Power motor
24	Gear Wheel	56	Motor plate
25	Gear	57	Tensioning Bolt
26	Gear Box Cover	58	Universal Gear
27	Coupling	59	Equivalent gear
28	Coupling	60	Gear Box Cover
29	Coupling Shaft	61	Coupling
30	Coupling	62	Coupling
31	Gear Box Cover	63	Coupling Shaft
32	Universal Gear		






SAYFA NO	CONTROL PANEL WITH DIGITAL			SAHINLER	
	MRM-S	TARİH	PLAN NO	DOSYA ADI	METAL MAKİNA SANAYİ AŞ
03		08/08/2005		MRM-S	


CALIBRATION




CLOSE THE MACHINE




DIGITAL MUST BE CLOSED TOO





PRESS THE "CAL" AND "PRG"
BUTTONS AND HOLD DOWN



AT THE SAME TIME OPEN THE
MACHINE




WHEN MACHINE OPEN STOP
HOLDING DOWN




TAKE DOWN THE ROLL TO MIN LEVEL
(THE ROLL WHICH YOU MAKE
THE DIGITAL SETTINGS)




PRESS THE RESET BUTTON




TILL THE VALUE BE ZERO




THEN PRESS THE "CAL" BUTTON




FOR ENTERING THE PASSWORD
USE UP&DOWN BUTTONS




WRITE "53"




PRESS "PRG" BUTTON ON THE
SCREEN YOU WILL SEE "CAL-1"




CHECK AGAIN THAT THE ROLL IS IN
THE LOWER MOST




PRESS "PRG" BUTTON





SCREEN YOU WILL SEE "CAL-2"




WHEN VALUE IS "300" LIFT THE ROLL TO THE MAX LEVEL



CHECK THAT THE ROLL IS ON THE MAX LEVEL



CALCULATE THE PISTONS
MAX mm LEVEL



CALCULATE IT FROM THE WHITE
COLOURED PLACE



ENTER THE VALUE THAT YOU
MEASURE ex IF YOU MEASURE 235
mm THEN ENTER 235 ON DIGITAL



PRESS "PRG" BUTTON