

V189 – WVF-265 Installation guide

1. Lining up and screwing base to bench



2. Temporary screw rear Jaw in position & mark holes



3. Drilling clearance hole on both rear & front vice jaws



4. Screw rear vice Jaw in position



5. Attach front jaw to screw handle



6. Line up front vice & wind tight in lock position



7. Screw front vice to handle end casting



8. Checking final alignment & winding action

