


A038A 3/8" Drill



RP7101 SPARE PARTS LIST

No.	Description	No.	Description	No.	Description	No.	Description
1	Housing	10	Bushing	19	Rotor Blade	28	Bearing
2	Pin	11	Controller	20	Steel wire	29	Clamp nut
3	Exhaust Deflector	12	O-ring	21	Rotor	30	Washer
4	O-ring	13	Spring	22	Front Plate	31	Chuck
5	Air Inlet plug	14	Trigger	23	Gear wheel	32	Chuck screw
6	Valve Stem	15	Gasket	24	Washer		
7	O-ring	16	Bearing	25	Idle Gear		
8	O-ring	17	End Plate	26	Pin		
9	O-ring	18	Cylinder	27	Gear shaft		