


# A086 Spare Parts List



2006.04.01

## PT-306M

Index No.	Parts No.	Description	Q'ty	Index No.	Parts No.	Description	Q'ty
1	306001	Exhaust Diffuser	1	20A	SS-0406A	Set Screw(M4x6)	1
3	306003	Air Inlet	1	22	302021	Internal Gear	1
4	SP-25220	Pin (M2.5x22)	1	23	305007	Planet Gage	3
5	306005	Motor Housing	1	23A	305007S	Planet Gage(306S)	3
5A	SB-008	Steel Ball (1/4")	1	24	306024	Planet Gage	1
7	BB-06261	Ball Bearing(626zz)	2	24A	NR-40138	Needle Roller(4x13.8)	3
8	302027	End Plate	1	25	BB-62012C	Ball Bearing (6201zz)	2
9	SP-25060	Pin (2.5x6)	1	26	306026	Clamp Nut	1
10	302024	Rotor	1	29	305021	Spring	1
11	302026	Cylinder	1	31	306M31	Spacer	1
12	302023	Front End Plate	1	32	BB-R82	Bearing	1
13	302025	Rotor Blade	4	33	306M33	Excentric Nut	1
14	ORP-0140	O-Ring(P14)	1	34	306M34	Cutter-Housing	1
15	305022	Valve Stem	1	35	306M35	Lock Nut(3/16"-24UNC)	3
16	ORP-0035	O-Ring(3.5*1.5)	1	36	306M36	Lock Screw(3/16"-24UCNx30)	3
16A	317005	O-Ring(3.9x2.25x2)	1	37	306M37A	Left Blade	1
17	ORP-0120	O-Ring (P12)	2	38	306M38	Spacer	2
19	306019	Valve Body	1	39	306M39A	Center Blade	1
20	305020	Trigger	1	40	306M40A	Right Blade	1