



REPLACEMENT PARTS LIST

Key No	Part No.	Description	Q'ty	Key No.	Part No.	Description	Q'ty
1	DA-D01	Motor	1	40	DA-D18	Connecting Link	2
2	5A-A306	Hex. Hd. Scr. M6x1.0P-30	4	41	DA-D19	Crank Pin	1
3	LK-Y13	Drill Chuck 1/2"	1	42	DA-D20	Crank Pin	1
4	5E-A004	Washer ϕ 1/4"	8	43	DA-D21	Crank Arm	1
5	DA-D02	Head Body	1	44	5F-E308	Roll Pin ϕ 8-50 μ	3
6	5E-A023	Washer ϕ 17mm	1	45	DA-D22	Crank Shaft	1
7	5B-A009	Hex. Nut M16x1.5P	1	46	DA-D23	Connecting Bend	1
8	5A-C403	Set Scr. M8x1.25P-16	1	47	DA-D24	Operating Lever	1
9	DA-D03	Holder, Chisel ϕ 13/16"	1	48	5F-E213	Roll Pin ϕ 5-50 μ	1
10	DA-D04	Chuck Guard	1	49	5A-B405	Soc. Hd. Cap Scr. M8x1.25P-35	2
11	DA-D05	Depth Setting Bar	1	50	DA-D25	Worktable	1
12	5A-G004	Lock Knob M8x1.25P-16	1	51	DA-D26	Table Insert	1
13	5A-L101	Scr., T-Cap	1	52	5A-E201	Counter Sunk Hd. Scr. M5x0.8P-10	2
14	5A-L001	Bolt, Setting M8x1.25P-15	1	53	DA-D27	Strip	1
15	DA-D06	Collar Stop	3	54	DA-D28	Collar, Stop	1
16	5A-C301	Set Scr. M6x1.0P-6	7	55	DA-D29	Bar, Setting	1
17	5B-D004	Self-Locking Nut M8x1.25P	1	56	DA-D30	Plate, Clamp	1
18	5A-B404	Soc. Hd. Cap Scr. M8x1.25P-30	3	57	DA-D32	Guide Rod	1
19	DA-D08	Locating Block	1	58	DA-D33	Base, Clamp	1
20	JH-T07	Spring	2	59	DA-D31	Lead Screw	1
21	5I-B103	Steel Ball ϕ 8	2	60	5F-E257	Roll Pin ϕ 6-36 μ	2
22	DA-D07	Stop Plate	1	61	DA-D34	Knob	1
23	5A-A414	Hex. Hd. Scr. M8x1.25P-50	1	62	DA-D35	Rack	1
24	DA-D10	Column, Morticer	1	63	DA-D36	Lateral Slide	1
25	DA-D12	Strip	1	64	DA-D42	Strip	1
26	5A-A405	Hex. Hd. Scr. M8x1.25P-30	9	65	DA-D37	Gear	2
27	5E-A009	Washer ϕ 5/16"	13	66	DA-D39	Collar, Setting	2
28	5E-A012	Washer ϕ 1/2"	3	67	DA-D38	Shaft Operating	1
29	5A-A605	Hex. Hd. Scr. M12x1.75P-40	3	68	DA-D40	Handwheel	1
30	DA-D11	Rear Cover	1	69	5F-E256	Roll Pin ϕ 6-32	3
31	5A-D401	Scr., Pan-Head M6x1.0P-10	4	70	DA-D41	Lead Screw	1
			3	71	DA-D43	Base	1
33	DA-D13	Special Screw	6	72	5A-A410	Hex. Hd. Scr. M8x1.25P-60	4
34	DA-D14	Pulley	1	73	DA-D44	Stand	1
35	DA-D15	Suspension Rope	1	74	DA-D45	Hook Bolt	2
36	5A-A302	Hex. Hd. Scr. M6x1.0P-12	1	75	DA-03A	Holder, Chisel ϕ 3/4"	1
37	DA-D16	Counterbalance Weight	1	76	DA-D46	Grip Rubber	1
38	DA-D17	Slide, Vertical	1	77		Magnetic Switch	1
39	5F-A011	Retaining Ring Ext. STW-20	4				

Note: When ordering repair parts always give the following informations:

* Model Number * Name of Item * Key No. * Part No. * Part Description