

Grinding Wheel
 Levee
 Hex. Nut
 Meshshield Set
 Right Int. Cover A
 Right Wheel Cover A
 Screw
 Left Int. Cover A
 Left Wheel Cover A
 Toolrest

50. Hex. Bolt
 51. Washer
 52. Right Int. Cover B
 53. Right Wheel Cover B
 54. Left Int. Cover B
 55. Left Wheel Cover B
 56. Wire Brush
 57. MOP/Buffer
 58. Set Screw
 59. Balance Block

60. Washer
 61. Balancing Flange
 62. Rotor Shaft*1
 63. Rotor Shaft*2
 64. Dust Collector
 65. Hex. Bolt
 66. Washer
 67. Chip Outlet
 68. Screw
 69. Spring Washer

70. Starting Capacitor *
 71. Clamp *
 72. Hex. Nut *
 73. Wiring Board

44+45+47+48 for GR type
 47+48+52+53 for CN type
 52+53+54+55 for PR type

*1 for CN type
 *2 for PR type

*for GR 10, CN10 only
 (Single phase)

