



PARTS LIST

CODE	PARTS NO	DESCRIPTION	Q'TY
1	427001	Housing-Upper	1
2	427002	Guard-Impeller	1
3	427003	Seal-Housing	1
4	427004	housing-Lower	1
5	427005	Sleeve-Housing Edge	1
6	427006	Motor	1
7	423023	Seal-Motor	1
8	430006	Fan	1
9	427009	Motor Plate	1
10	430034	Motor Plange Packing	1
11		Cord-Power	1
12	427012	Seal-Housing Lower	1
13	427013	Stand-Upper	1
14	427014	O-Ring	1
15	427015	Stand-Lower	1
16	427016	Seal-Base	1
17	427017	Guard-Base	1
18	427018	Base	1
19	427019	Caster-Fixed	2
20	427020	Caster-Pivoting	2
21	427021	Supporting Bar	2
22	427022	Handle	1
23	427023	Holder-Dust Bar	1
24	422028	Clamp-Dust Bag	2
25	427025	Bag-Upper	1
26	427026	Clear Bag-Plastic	5
27	427027	O-Ring	1
28	427028	Pipe-Inlet	1
29	420203	Cover-Inlet	2
30	992021	Pin	1
31	994532	Switch	1

CODE	PARTS NO	DESCRIPTION	Q'TY
32	430007	Hub-Impeller	1
33	427033	Guard-Air	1
34	990805	Screw	28
35	990811	Screw	11
36	990912	Round Head Screw	8
37	990111	Hex. Screw	4
38	990131	Hex. Screw	8
39	990313	Screw-Hex Hole	2
40	990114	Hex. Screw	2
41	990113	Hex. Screw	8
42	998623	Strain Relief	1
43	990118	Hex. Screw	4
44	991452	Nut Acorn	2
45	991111	Nut-Hex	8
46	991112	Nut-Hex	2
47	991221	Nut-Hex	2
48	991921	Lock Washer	8
49	991931	Lock Washer	8
50	991941	Lock Washer	2
51	991712	F. Washer	4
52	991743	F. Washer	4
53	991821	F. Washer	1
54	991751	F. Washer	2
55	991373	Nut-Hex	1
56	427056	Plug-Plastic	2
57	427057	Supporting Block	2
58	427058	Extension Goard	1
59	990132	Hex. Screw	8
60	990912	Round Head Screw	6
61	990111	Hex. Screw	4
62	990131	Hex. Screw	2

