


A348 360 KG 31/7/03

MOTORCYCLE LIFT

Do not overload. Overloading could cause damage to or failure of the motorcycle lift.

Always use motorcycle lift on hard, level surface.



| PARTS NO | DESCRIPTION | QTY | PARTS NO | DESCRIPTION | QTY |
|----------|-----------------|-----|----------|------------------------|-----|
| 1 | Baffleplate | 1 | 7 | Brace | 1 |
| 2 | Bolt M10x40 | 2 | 8 | Flat Washer Ø8 | 8 |
| 3 | Flat Washer Ø10 | 2 | 9 | Nut M8 | 8 |
| 4 | Nut M10 | 2 | 10 | Base Frame | 1 |
| 5 | Handwheel | 1 | 11 | Sloping Plate Assembly | 1 |
| 6 | Bolt M8x40 | 8 | 12 | Extension Leg | 2 |

A348

360KG MOTORCYCLE LIFT

EXTRA INSTRUCTIONS

**ALWAYS USE LIFTER WITH THE REAR 2 LEGS
UNDER THE RAMP IN THE EXTENDED POSITION**

**NEVER USE THE LIFTER IN THE UP
POSITION WITHOUT PUTTING THE
SAFETY BAR SUPPLIED THROUGH
THE HOLES IN THE BASE IN FRONT
OF THE SCISSOR ROLLERS**

**ALWAYS HAVE THE MOTORBIKE ON THE
CENTRE STAND AND THE FRONT WHEEL
CLAMPED SECURELY BEFORE LIFTING THE
PLATFORM**