




Industrial Floor Fan OPERATION MANUAL




FD-45



Edition No : FD-001

Date of Issue : 10/2016

SPECIFICATIONS



1. Front Safety Grill
2. Rear Safety Grill
3. 3 Speed Switch
4. Fan Motor (On Rear Of Fan)
5. Right Locking Tilt Nut
6. Floor Stand
7. Fan Blade
8. Left Locking Tilt Nut

Voltage


Check the voltage on the specification plate is the same as the local voltage. Do not use if they are not compatible and contact your dealer.

The fan must be earthed to the socket.

Speed Control

The fan has a speed control, "0" is off, "3" is the fastest, "1" is the lowest.

Model	FD-45
Size (mm)	450
Volt	240
Hz	50
Watts	165
Air Flow	130
Speed	1400
Speeds	3



A	B	C	D
570	240	518	560

SAFETY INSTRUCTIONS

When using this electrical appliances, basic safety precautions should always be followed, to reduce the risk of fire, electric shock and personal injury,

- Carefully read this instruction manual before using the appliance.
- Keep young children out of reach of the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised around the appliance to ensure that they remain in a safe environment
- Ensure that appliance does not get wet (water splashes etc.).
- Do not use appliance with wet hands.
- Always operate the appliance from a power source of the same voltage, frequency and rating as indicated on the product identification plate.
- Position the power supply lead correctly so that it will not be walked on or pinched by items placed on or against them.
- Use appliance only for its intended use.
- Do not use appliance if it has been dropped or any part of appliance (including cord or plug) has been damaged. Take appliance to your nearest authorized service center or qualified dealer for inspection or repair.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Appliance should not be used outdoors, placed near a hot gas or electrical burner or placed in a heated oven.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- Do not operate appliance underneath or near flammable or combustible materials (e.g. curtains). Keep at least 300mm clearance around sides, back, front and top.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Do not block any ventilation openings.
- Turn off and unplug before cleaning or storing.
- Any type of servicing, apart from ordinary cleaning, must be carried out by an authorized service center or qualified dealer.
- If this appliance is used by a third party, please supply the instruction manual with it.
- Do not misuse the cord. Never carry the appliance by the cord or pull to disconnect it from the outlet. Instead, grasp the plug and pull to disconnect.
- Do not insert or allow foreign objects to enter the grille openings as this may cause damage to the appliance and/or injury to the user.
- No liability can be accepted for any damage caused by non-compliance with these instructions or any other improper use or mishandling of appliance.

TILT ADJUSTMENT

To adjust and tilt the fan body; first disconnect the fan from the power supply wall socket, then loosen both locking tilt knobs (5 & 8) located either side of the fan by rotating anti-clockwise the knobs

2. Tilt the fan to the desired position.
3. Re-tighten the locking tilt knobs (5 & 8) located either side of the fan.
4. Plug the fan back into the wall socket and turn ON to the desired speed using the 3 speed switch



MAINTENANCE

When the fan is not in use, it should be cleaned and packed making sure the power lead is protected.. It then should be stored in a dry place. Ensure that the fan is not in a place where it could be damaged.